

## NOVA - Gsm Communication Card

It serves to notify the user of the alarm status via GSM in the addressable NOVA fire warning prompt. This feature is suitable for use on NOVA AFCP-B and AFCP-M Models only. NOVA-GSM Card can send SMS to 3 different phones in case of Alarm or ERROR or both events. SMS's are sent in the Language of the Panel to which the GSM CARD is connected. In addition, it can mute the Buzzer, disable the Siren, Flasher or PIL or outputs activated by the scenario, and reset the Panel from the phones you have authorized. The explanation for this function is detailed below. GSM Card connected to panel by RS485 Network or TCP/IP, if it is connected to the network it will send the information to the Panel from here as an SMS. And you can control the network Panels with the Remote control.

